



EUROPOWER®

www.EUROPOWERGenerators.com



An ISO 9001 approved company

Stroomaggregaten met **BRIGGS & STRATTON INTEK** of **VANGUARD** luchtgekoelde benzinemotor
Groupes électrogènes avec moteur essence **BRIGGS & STRATTON INTEK** ou **VANGUARD** refroidi par air
Stromerzeuger mit **BRIGGS & STRATTON INTEK** oder **VANGUARD** luftgekühltem Benzinmotor
Generating sets with **BRIGGS & STRATTON INTEK** or **VANGUARD** air-cooled petrol engine
Grupos electrógenos con motor **BRIGGS & STRATTON INTEK** o **VANGUARD** gasolina refrigerado por aire

10 - 20 kVA

50 Hz - 3000/min

4-Takt / 4 temps / 4 stroke / 4 tiempos



EP1000T



EP16000E/EP20000TE

TYPE TYP TIPO	kVA max.	kVA cont.	Amp.		Motor Moteur Engine BRIGGS & STRATTON	kW	cm ³	Tank Réservoir Dépósito (l)	Autonomie Autonomy Autonomía (h at 75% load)	Uitvoering Version Ausführung Modelo	Afmetingen Dimens. Maße (cm)	kg	dB(A) @ 7m	Lwa
			1 ~ 230V	3 ~ 400V										
EP1000T	10	9	15	11	16 HP VANGUARD V-TWIN	11	480	8,5	2,4	B-F-OP-R-TM	83x55x60	95	75	*
EP16000E	16	14,5	63	-	31 HP VANGUARD V-TWIN	23	895	41	5,8	A5-E-F-FG-FPm-h-OP-TM-V	100x64x72	210	79	*
EP20000TE	20	18	26	21						B4-E-F-FG-FPm-h-OP-TM-V				

A = 2 stopcontacten 230V - 16A / 2 prises 230V - 16A / 2 Steckdosen 230V - 16A spritzwassergeschützt / 2 Sockets 230V - 16A / 2 tomas 230V - 16A

A4 = 1 stopcontact 230V - 16A + 1 stopcontact CEE 230V - 63A / 1 prise 230V - 16A + 1 prise CEE 230V - 63A / 1 Steckdose 230V - 16A + 1 Steckdose CEE 230V - 63A / 1 Socket 230V - 16A + 1 Socket CEE 230V - 63A / 1 toma 230V - 16A + 1 toma CEE 230V - 63A

B4 = 1 stopcontact 230V - 16A + 1 stopcontact CEE 230V - 32A + 1 stopcontact CEE 400V - 32A 5-polig / 1 prise 230V - 16A + 1 prise CEE 230V - 32A + 1 prise CEE 400V - 32A 5 pôles / 1 Steckdose 230V - 16A + 1 Steckdose CEE 230V - 32A + 1 Steckdose CEE 400V - 32A 5-polig / 1 Socket 230V - 16A + 1 Socket CEE 230V - 32A + 1 Socket CEE 400V - 32A 5-pole / 1 toma 230V - 16A + 1 toma CEE 230V - 32A + 1 toma CEE 400V - 32A 5-polos

E = Elektrisch gestart incl. accu / Démarrage électrique (batterie incluse) / Elektrostart mit Batterie / Electric Start (Battery included) / Arranque eléctrico (batería incluida)

F = Frame / Cadre / Gestell / Frame / Chasis

FG = Mechanische brandstofniveaumeter / Jauge mécanique carburant / Mechanische Kraftstoff-Uhr / Mechanical fuel level meter / Indicador del nivel de combustible mecánico

FPm = Membranbrandstofpomp / Pompe à membrane / Membran-Kraftstoffpumpe / Membrane fuel pump / Bomba membrana de combustible

OP = Oliedrukbeveiliging / Sécurité pression d'huile / Öldruck-Abschaltautomatik / Low oil pressure guard / Protección de presión de aceite

R = Repeteerstarter / Lanceur à rappel / Reversierstarter / Recoil Starter / Arranque reversible

TM = Thermo-magnetische beveiliging / Protection thermo-magnétique / Thermisch magnetischer Schutzschalter / Thermal Magnetic breaker / Disyuntor termomagnético

V = Voltmeter / Voltmètre / Spannungsmesser / Voltmeter / Voltímetro

* = Generators marked with an * cannot be used outdoors in the EU. For applications of generators indoors or if you want to integrate these generators in vehicles, please contact us.